



wedi PreLine




Preparation – for mineral surfaces



1. All surfaces must be firm, load-bearing, non-deformable and free of dust, dirt and other contaminants. Any unevenness must be levelled out with suitable levelling compounds. The surface must be dry and ready for covering. Particularly newly created surfaces must be sufficiently dried so that the shrinking process which results from drying is complete before installation of the wedi PreLine. (Max. residual moisture content: cement screeds 2.0 CM-%, calcium sulphate screeds 0.5 CM-%)
2. Primer must be applied to highly absorbent, mineral substrates (e.g. anhydrite screeds). Any bonding agent concentration on the surface (sintered layers) must be removed first. Edge insulation strips must then be applied.


Preparation – wooden surfaces




It is important for the surface on the wooden beam coating to be properly implemented before installation of the wedi PreLine system is begun.

There are special requirements for the strength and rigidity of wooden beams in wet rooms with the use of non-elastic floor coverings such as tiles. The wedi PreLine system can absorb small movements from the substructure, but the tile lining cannot. It is therefore a basic prerequisite that the structures used do not have any deformation.

Laying – wedi PreLine




The wedi PreLine is laid across the full surface with a thin-bed mortar (recommendation: wedi 320 universal tile adhesive) and aligned. In wet areas, the building board joints must be fully and thoroughly bonded and sealed with wedi 610 adhesive sealant (recommendation: one bead of wedi 610 underneath the milling groove and one bead level with the milling groove).



In wet areas, the open ends of the groove in the edge areas of the wedi PreLine must be waterproof.

2.A Finish the joints all round the wall areas with a wedi building board strip (approx. 5 cm) of the same thickness as the wedi PreLine element. The edges must be fully sealed with wedi 610 adhesive sealant.


2.B Another form of sealing of the groove is to glue in wedi building board strips (length x width x thickness approx. 50 x 14 x 12.5 mm) and seal with wedi 610 adhesive sealant.



Lay pipes in the groove. Backfill the pipe ducts with tile adhesive, e.g. wedi 320 tile adhesive.



In wet areas, the building boards / wall connections must be implemented with a sealing tape using a liquid sealant (recommendation: wedi Tools sealing tape with wedi 610 or wedi 520). All intersections in the wedi PreLine must be properly sealed.



The entire surface must be covered with 600 mm wide, self-adhesive reinforcement tape (recommendation: wedi Tools 600 mm joint reinforcement tape).



Ceramic tiles with a minimum size of 10 × 10 cm can be laid on this surface. The wedi PreLine can be tiled directly after reinforcement without further pretreatment. Laminate or complete parquet must be laid as a floating floor.

(Note: the use of wood surfaces may reduce the thermal conductivity).



wedi GmbH
 Hollefeldstraße 51
 48282 Emsdetten
 Germany

Telephone +49 2572 156-0
 Fax +49 2572 156-133

info@wedi.de
 www.wedi.eu

wedi Systems (UK) Ltd
 Unit 4 Mercury Park · Mercury Way
 Trafford Park · M41 7LY
 Great Britain

Telephone +44 161 864 2336
 Fax +44 161 864 1323

info@wedi.co.uk
 www.wedi.co.uk